



ATC3600

Product Features:

- 8.3-oz, 100% ringspun polyester jersey with wicking technology
- UV protection = UPF 38+

Adult sizes: XS-4XL

Icons/Fabric Features:



Available Colours and PMS Colours

Textile fabric colours are subject to dye lot variation and will not be exact match to print pantone reference



Due to the nature of polyester, special care must be taken throughout the decoration process.

ATC3600 - ATC™ Pro Spun™ Tee

GARMENT MEASUREMENTS

Size	XS	S	M	L	XL	2XL	3XL	4XL
Chest - <i>Half Measure</i>	18"	19 1/2"	21"	22 1/2"	24"	25 1/2"	27 1/2"	29 1/2"
Chest - <i>Full Measure</i>	36"	39"	42"	45"	48"	51"	55"	59"
Body Length from HPS (At back)	27 1/2"	28 1/2"	29 1/2"	30 1/2"	31 1/2"	32 1/2"	33"	33 1/2"
Sleeve Length-CB	17 1/4"	18"	18 3/4"	19 1/2"	20 1/4"	21"	21 3/4"	22 1/2"

Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.

ADULT General Sizing Guide

Size	XS	S	M	L	XL	2XL	3XL	4XL
Chest	30"-32"	34"-36"	38"-40"	42"-44"	46"-48"	50"-52"	54"-55"	56"-57"
Waist	26"-29"	29"-32"	32"-35"	35"-38"	38"-41"	41"-44"	44"-47"	47"-50"
Sleeve Length-CB	31"-32"	32"-33 1/2"	34"-35"	35"-36"	36"-37"	37"-38"	38"-39"	38 1/2"-39"



DECORATING INSTRUCTIONS FOR PRO SPUN STYLES

GENERAL:

- Pro Spun feels very much like cotton, but is 100% Polyester.
- 100% polyester is heat sensitive and cannot exceed temperature thresholds higher than 320 degrees or shrinkage, bleeding or spot staining may occur.
- Polyester requires a longer cooling time than cotton. Avoid overlap of garments and decoration until garments are cooled. Failure to cool the fabric prior to stacking into a printer's fold may cause the fabric and applied decoration to stick together.
- Recommended decorations: Screenprinting, Heat Transfer, Embroidery
- Direct to garment (DTG) is primarily used on cotton fabrics. Check with your supplier for information on requirements for DTG process on 100% polyester.

SCREEN PRINTING:

- Work with your ink supplier to select the correct ink for your project. We recommend using low cure materials and a grey barrier base bleed blocker, especially on dark colors.
- When screen printing on 100% polyester, be sure to monitor the heat at flash and dryer temperatures.

HEAT TRANSFERS:

- Work with your heat transfer supplier to select the correct ink for your project. We recommend using an anti-migration layer in the designs.
- Check with your heat transfer machine supplier to determine correct temperature, time and pressure for your project.